Docket No. SA-537
Exhibit No. 6-AA

NATIONAL TRANSPORTATION SAFETY BOARD

Washington, D.C.

Air Cruisers Presentation Airplane Cabin Crashworthiness & Occupant Protection

(10 Pages)



Air Cruisers Proprietary Information for exclusive use of NTSB and Investigation Participants. Not to be copied or distributed without written authorization. All Rights Reserved.

MASTERING THE ELEMENTS



Introduction

- Air Cruisers was founded in 1929 as maker of **Aviation Safety Equipment**
- Manufactured "Mae West" Life Preservers and Barrage Balloons during WW2
- Invented & patented Inflatable Evacuation Slides in 1950's
- Air Cruisers was purchased by Zodiac in 1987 which became Zodiac Aerospace in 2007















What is an Evacuation Slide?

- Safety device that rapidly inflates for emergency evacuation from an aircraft
- Required on commercial aircraft when exit height exceeds 6 feet from ground
- Normally installed inside the cabin on the door, or housed in an external fuselage compartment
- Many slide designs double as a raft for ditching (water landings)









Typical Primary Major Components

- Packboard & Lacing cover
 - Contains slide assembly
 - Provides mounting hardware to attach to the aircraft door
- Inflatable tube structure
- Inflation System
 - Compressed gas reservoir
 - Valve/Regulator
 - Hose(s)
 - Aspirator(s)
- Survival Kit (for slide/rafts)
 - Includes Raft Canopy














Typical Slide Particulars






How Does an Evacuation Slide Work?

- The Packed Slide System is installed on the aircraft
- The "Girt Bar" is attached to the aircraft floor fittings
- When the aircraft door is "armed" and opened a cable is tensioned that releases the Slide pack from its packboard
- The Slide begins to drop downward and the inflation cable is pulled, opening the valve to initiate inflation









How Does an Evacuation Slide Work?

- Gas rushes to the Aspirators, opening their flappers which entrain ambient air
- The unfolding of the Slide occurs in stages, controlled by frangible attachments (links)
- The Aspirator flappers close when the slide pressure builds
- The Slide is rapidly inflated and immediately ready for use once fully extended












What are the Requirements?

- FAA TSO-C69c is the primary governing document
- Typical Slide Design/Test programs take 3-4 years to complete
- TSO-C69c Performance Requirements include:
 - Inflation Time maximum 6 seconds
 - Evacuation Rate (minimum) 70 persons per minute per lane
 - Deploy in 25 knot wind
 - Resist the Environment (sand, dust, salt spray, fluids, rainfall, etc.)
 - Radiant Heat Reflective Fabric
 - Flame Resistance and Smoke and Toxicity requirements per applicable FARS.
 - Resist Temperature extremes (-40 to +160 deg. F)
 - Function at Adverse Attitudes (Any combination Landing Gears out)
 - Function in Water Landing "Ditching" conditions
 - Usable as deflated "chute"



What are the Requirements?

- Additional Requirements from OEM's for certification of the aircraft
 - Vibration
 - Shock
 - On-Aircraft repeatability
 - Full Scale Evacuation Demonstration per FAR 25.803
 - Acceleration Loads per FAR Part 25.810 (a) (1) (v)











Air Cruisers Proprietary Information for exclusive use of NTSB and Investigation Participants. Not to be copied or distributed without written authorization. All Rights Reserved.

Mastering The Elements

